

PRODUCT INFORMATION

TISPLUS" USER GUIDE

TISPLUS SCAN HANDLE FOR DOLPHIN 70e/75e

1. STYLUS USAGE

Before insertion please attach your stylus to the TISPLUS Scan Handle. There is a loop and a stylus holder on the right side of the handle. The scan handle is not designed to use a device with attached stylus tether.





NOTE: Please do not insert the device when the scan handle is in locked position, this could damage the locking mechanism and the connector pins.

2. INSERTION

Before inserting the device make sure the scan handle is in the <u>unlocked position</u>. If rev. and date-code are visible, it is in the locked position, if not, it is in the unlocked position (right picture).





Push the device into the cradle until the Release Button snaps in with a "click".



3. REMOVAL

Press the release Button until the cradle moves in the unlocked position. Now pull the device forward and take it out of the cradle.



File: TISPLUS SCAN HANDLE FOR DOLPHIN 70e/75e Stand: 15.04.2016